

ASSEMBLY-OVERHEAD CONSOLE (Page No: 1 of 1)

Pin Name	Circuit Name	Function	Gauge	Color	Tracer Color
1	A413	FUSED B(+)	18	RD	WT
2	G38	UGDO ENABLE CONTROL CIRCUIT	22	GY	
3	E12	PANEL LAMPS DRIVER	22	OR	GY
4	N0				
5	Z923	GROUND	22	BK	
6	N0				
7	M24	COURTESY LAMPS DRIVER	22	YL	WT
8	M27	READING LAMPS DRIVER	22	YL	LB
9	Q3	SUNROOF OPEN SWITCH SENSE	22	OR	DG
10	Q4	SUNROOF VENT SWITCH SENSE	22	OR	YL
11	Q5	SUNROOF CLOSE SWITCH SENSE	22	OR	LB
12	Q6	SUNROOF SWITCH SUPPLY	22	OR	LG
13	Q56	CNV - SUNROOF_SHADE_PWR_CLOSE_(+)	22	OR	VT
14	Q556	CNV - SUNROOF_SHADE_PWR_OPEN_(+)	22	OR	GY
15	G25	DECKLID/LIFTGATE RELEASE SWITCH SENSE	22	VT	TN
16	Z919	GROUND	22	BK	